

ThanoTech

Reliable innovation for the funeral professional

1846 W. Ash Ave.
Fullerton, Ca., 92833
Cell (714) 612-1209
Fax (714) 525-6172
www.thanotech.com

Description: ThanoSeal™ is an occlusive incision and wound sealant made of high strength polymer film with an extremely aggressive adhesive back.

Usage: ThanoSeal™ can be used to seal incisions, punctures, lacerations, abrasions and skin slip. It is intended for use by embalmers and funeral professionals and should never be applied to living tissue.

Directions:

1. Close incision or wound by embalmers preferred method, then clean and dry area around incision or wound. *Any moisture or debris on the tissue can cause ThanoSeal™ not to seal completely, with the potential of allowing leakage in some circumstances.
2. Select ThanoSeal™ patch or tape size suitable to cover wound area and surrounding tissue. Make it large enough so as to seal the area completely.
3. Apply firm even pressure to ThanoSeal™ to complete the seal.

Tips:

ThanoSeal™ should not be used on tissue below 55 degrees Fahrenheit.

A cotton based product is most effective for cleaning application area.

ThanoSeal™ can be applied after embalming, it can also be applied just prior to dressing a case as well.

It's recommended that ThanoSeal™ patch product be handled with forceps on one of the corners, to minimize unintended contact of ThanoSeal™ with tissue, gloves or other objects. The adhesive is very aggressive and once in contact with tissue, gloves or other object it can compromise the hold of the adhesive.

Once applied to tissue, apply pressure over the entire surface to get maximum hold.

The ThanoSeal™ tape product has an 80/20 backscore backing, remove the 80 % backscore portion, apply to incision or wound and then remove 20 % of backing, apply pressure to entire area of ThanoSeal.

Distributed by:

