

Protocol for Sutureless Incision Closure

1. Prep incisions as normal by tying off vessels, cleaning and drying.
2. Add drying powder into incision.
3. Clean and dry area surrounding incision. Any debris or moisture on tissue will prevent ThanoSeal™ from forming a complete seal with tissue and could potentially leak.
4. Close incision with an instant glue (cyano-acrylic, i.e. super glue or arron alpha).
5. Using the appropriate size ThanoSeal™ patch or tape apply over the top of the incision.
6. Use firm even pressure on ThanoSeal™ to ensure complete seal over entire patch.

Tips: Do not use ThanoSeal on tissue that is less than 55 degrees Fahrenheit.

Use forceps to handle ThanoSeal™ patches, to limit contact with adhesive and gloves.

When using ThanoSeal™ tape product remove larger section of backing and apply to tissue then remove smaller section and complete application by using firm pressure over entire ThanoSeal™ product.